


TOWER UNIT Boiler Housing Assembly Guide



Vogue TOWER UNIT


Boiler Housing Assembly Guide





NB. All Cam Lock (H) are to be positioned facing

the outside of the unit carcase, for ease of tightening.



Seat (G)

shown.

RH

F F G

Cam Dowel into hole as

Dowel (F) & Cam Dowel (G) location detail

Btm


G


G

LH

G F F

Do **not** use power tools with cam dowel **(G)** or cam lock **(H)**








Vogue TOWER UNIT

Boiler Housing Assembly Guide



Step 7.Push leg firmly down into leg base. Adjust legs to 155mm before turning unit upright. Once in situ level accordingly.






Step 5.

Position legs as shown. Ensure legs are rotated to also provide support to the end panels **(B)**.


Step 6.

Secure each of the legs into place with 4 x 15mm screws **(L)** per leg.



Step 8.Attach hinge plates onto end panels **(B)** to suit as shown using screws already located in the hinge plates.

Hinge side or sides to be mounted in accordance to Customer Specific Kitchen Plan.






Step 9.

Attach hinge plates onto end panels **(B)** to suit as shown using screws already located in the hinge plates.

Hinge side or sides to be mounted in accordance to Customer Specific Kitchen Plan.







Screws for attaching to walls are not provided as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall construction are used.


Screw into any side units using the 30mm screws **(K)** provided to secure to unit.

Screw just to the rear of the hinge mounting plates, at the top and bottom of both sides of the unit, place cover caps **(M)** on the heads to conceal them.



Secure tower to the wall using L brackets LGE. Use 2 x 15mm screws **(L)** to secure each of the L bracket LGE to the unit at either side. Then screw through into the wall as shown.






Vogue TOWER UNIT

Boiler Housing Assembly Guide

See Customer Specific Kitchen Plan For Tower Frontals




Step 10.

Insert hinge where required in holes as shown.

Step 11.

Secure hinges by tightening 2 x screws with hinge dowels attached. These are already positioned within the hinges.




Step 12.

Align doors to join together using 2 x fixing plates **(U)** to the back of both frontals ensure a 4mm gap is maintained between each frontal once fixed together.


Screw in place using 4×15 mm screws **(L)** per fixing plate.


Step 13. Adjust hinge to suit. As shown below.



Step 14.

Fit cover caps to hinge. Adjust Soft close to suit.







The top and bottom hinges **MUST** be adjusted to the **SAME STRENGTH.**

