
Vogne BASE UNIT


Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide






Vogne BASE UNIT


Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide



INSTALLATION SHOULD BE PERFORMED BY A COMPETENT PERSON ONLY.

THIS PRODUCT COULD
BE DANGEROUS
IF INCORRECTLY
INSTALLED











Step 1.

Secure drawer base to drawer side using 4 x 16mm drawer runner screws (J) in holes provided.


Seat the edge of drawer base tight into corner of casing, as shown.


The decorative face of drawer base to be positioned as shown.


Repeat step 1 so both drawer sides are attached to drawer base.

Step 2.

Clip on metal back panel to drawer base & drawer sides.








Step 3.

Screw back panel in position using 2 x 16mm screws (J) to drawer base in holes provided.



Vogne BASE UNIT

Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide


Step 1.

Secure drawer base to drawer side using 4 x 16mm drawer runner screws (J) in holes provided.

Seat the edge of drawer base tight into corner of casing, as shown.


The decorative face of drawer base to be positioned as shown.

Repeat step 1 so both drawer sides are attached to drawer base.



Step 2.

Clip on metal back panel to drawer base & drawer sides.



Front of drawer

Metal back panel

Step 4.

(Y) Gallery

Head

Fixing •

clip

& (O)


Screw back panel in position using 2 x 16mm screws (J) to drawer base in holes provided.


Deep drawer 231mm 231mm 231mm


Secure **drawer side fixing clips** using 2 x 21mm screws **(Q)** & **gallery head (Y)** using 1 x 15mm screws **(L)** in pilot holes provided as shown.

99mm

67mm









99mm

67mm





shown




Step 7.

Fixing

clip

& (O)


Fit drawer cover caps over drawer side adjustment.





BEFORE YOU START

INSTALLATION SHOULD BE PERFORMED BY A COMPETENT PERSON ONLY.

THIS PRODUCT COULD **BE DANGEROUS** IF INCORRECTLY
INSTALLED







Cam Dowel

(Expanding)



Cam Lock





(K) x4

30mm

Screw








(L) x12 15mm Screw


(M) x4 Cover Cap



Vogue BASE UNIT

Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide





Vogue BASE UNIT


Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide



Slide back panel (A) into groove of end panels (B).

The back panel **(A)** is to be modified accordingly to suit Customer Requirements, prior to inserting into unit.

Once back panel **(A)** is in position, ensure the panel is flush & square with bottom of end panels **(B)**.



600 unit used for reference only


Step 8.


Hand tighten all cam locks **(H)**, this will expand cam dowels **(G)** and tighten the unit together.

Step 9.

Ensure unit is square. Secure back panel **(A)** with 3 or 4 x 30mm screws **(K)** equally spaced at the bottom of back panel **(A)** into base panel **(C)**, as shown.

Ensure you screw into the centre of the base panels **(C)** (9mm from the edge).





Step 11.Secure each of the legs into place with 4 x 15mm screws **(L)** per leg.

Step 12.


Push leg firmly down into leg base. Adjust legs to 155mm before turning unit upright. Once in situ level accordingly.






Step 10.

Position legs as shown. Ensure legs are rotated to also provide support to the end panels **(B)**. 600-800 width unit, 4 legs 1000 width units, 5 legs.








Hob 2 Drw, 3 Drw & 2 Drw inc Dummy Assembly Guide





Screws for attaching to walls and worktop are not provided as these vary depending on materials, thickness and construction. Ensure appropriate fixings for wall and worktop construction are used. Please refer to the specialist worktop supplier if these are required for solid surface worktops.



Secure unit to wall by screwing through the back rail and into the wall.

Screw into any side units using the 30mm screws **(K)** provided to secure to the unit. Screw just to the rear of the indentations at the top and bottom on both sides of the unit where applicable. Place cover caps **(M)** on the heads of the screws to conceal them.





Screw up through the metal rail into worktop to secure it in place.

Dummy Drawer Frontal Fixing (Where Applicable)

Drawers Supplied in accordance to Specific Customer Kitchen Plan

Step 1.

Secure 2 x dummy fixing clip parts **(B)** onto the inside face of dummy draw front, **26mm** from the edge and **64mm** from the bottom, spaced evenly either side as shown, using 1 x 21mm screw **(Q)** per part **(B)**. Align so frontal is in line with adjacent frontals.

